Airguide

marine tachometer selection chart

HOW TO SELECT THE TACHOMETER YOU NEED:

1. Select the tachometer case style you desire.
2. Find your motor on the Tachometer Selection Chart.
3. Follow the motor model line horizontally to the selection style column to find tachometer model number.

YEAR	Model Number	TACHOMETER Series 10 & 20	TACHOMETER Sea Speed 2
	JOHNSON OUTBOARDS		
1979	70ELCS, CI, CN, CT	1029	
1978	75ERCS, CI, CN, CT, TRLCS, CI, CN, CT	1029	
1977	85MLCS, TLCS, TXLCS	2029	
1976	90MLCI, CN, CT, TLCI, CN, CT, TXCI, CN, CT	2029	870
THRU	100MLCS, TRLCS, TRXCS	1039	+
1973	115MLCS, CI, CN, CT, TLCS, CI, CN, CT, TXCS, CI, CN, CT	2039	■■■982
1972	140MLCS, TLCS, CI, CN, CT, TXCS, CI, CN, CT	+	
1968	150TLCS, CI, CN, CT, TXCS, CI, CN, CT	■■■982	
1967	175TLCS, CI, CN, CT, TXCS, CI, CN, CT		
	200TLCS, CI, CN, CT, TXCS, CI, CN, CT		
	235TLCS, CI, CN, CT, TXCS, CI, CN, CT		
1979	50ES71, 72, 73, 74, 75		
1978	50ESL71, 72, 73, 74, 75		
1977	55E76, 77; 55EL76, 77		
1976	60ES70, 71; 60ESL70, 71		
1975	65ES72, 73; 65ESL72, 73	1029	
1974	65SLR73		
1973	70ES74, 75; 70ESL74, 75		
1972	70ESLR74		
1971	70EL76, 77, 78, 79		
1970	75ESR75; 75ESLR75	2029	
1969	75ER76, 77, 78, 79; 75ELR76, 77, 78,78		
1968	85ESL69, 70, 72, 73, 74, 75		
1967	85EL76, 77, 78; 85ETLR76, 77, 78		
1966	85ML79; 85TL79; 85TXL79		870
1965	85TXLR77, 78		+
THRU	100ESL71, 72		■■■982
1960	100ML79; 100TLR79; 100TXLR79		
	115ESL69, 70, 73, 74, 75		
	115ETL74, 75, 76, 77		
	115EL76, 77, 78; 115ML79		
1979	115TXL77, 78, 79; 115TL78, 79		
1978	125ESL71, 72	1039	
	135ESL73, 74, 75		
	135ETL74, 75, 76	2039	
	135EL76		
	140ML77, 78, 79	+	
	140TL77, 78, 79; 140TXL77, 78, 79		
	150TL79; 150TXL79	■■■982	
	175TL77, 78, 79; 175TXL77, 78, 79		
	200TL76, 77, 78, 79; 200TXL76, 77, 78, 79		
	235TL78, 79; 235TXL78, 79		

YEAR	Model Number	TACHOMETER Series 10 & 20	TACHOMETER Sea Speed 2
	EVINRUDE OUTBOARDS		
1979	70ELCS, CI, CN, CT	1029	
1978	75ERCS, CI, CN, CT, TRLCS, CI, CN, CT	1029	
1977	85MLCS, TLCS, TXLCS	2029	
1976	90MLCI, CN, CT, TLCI, CN, CT, TXCI, CN, CT	2029	870
THRU	100MLCS, TRLCS, TRXCS	1039	+
1973	115MLCS, CI, CN, CT, TLCS, CI, CN, CT, TXCS, CI, CN, CT	2039	■■■982
1972	140MLCS, TLCS, CI, CN, CT, TXCS, CI, CN, CT	+	
1968	150TLCS, CI, CN, CT, TXCS, CI, CN, CT	■■■982	
1967	175TLCS, CI, CN, CT, TXCS, CI, CN, CT		
	200TLCS, CI, CN, CT, TXCS, CI, CN, CT		
	235TLCS, CI, CN, CT, TXCS, CI, CN, CT		
	40072,-073		
	50172,-173,-272,-273,-372,-373		
	50442,-443,-472,-473		
	55642,-643,-672,-673	1029	
	55742,-743,-772,-773		
	60072,-073,-172,-173	2029	
	65272,-273,-372,-373		
	70442,-443,-472,-473		
1976	70572,-573,-673,-773,-873,-973		
1975	75542,-543,-642,-643,-742,-743		
1974	75842,-843,-942,-943		
1973	85093,-293,-393,-493,-593,-693		870
	85790,-793,-799,-890,-895,-899		+
THRU	85990,-995,-999		■■■982
1960	100193,-293,-990,-993,-999		
	115083,-393,-493,-593,-693		
	115790,-793,-799,-890,-893,-899		
	115990,-993,-999		
1977	125183,-283		
1976	135383,-443,-483		
	135543,-583,-643,-683		
	140740,-743,-783,-840,-843,-883	1039	
	140940,-943,-983		
	150940,-949	2039	
	175740,-749,-840,-849,-940,-949		
	200640,-649,-740,-749,-840,-849	+	
	200940,-949		
	235840,-849,-940,-949	■■■982	

YEAR	Model Number	TACHOMETER Series 10 & 20	TACHOMETER Sea Speed 2
1979	**MERCURY OUTBOARDS**		
THRU	50E, 70, 80, 90	2029	1029
1984	115, 140, 150, 175, 200	2039	1039
	225		
1979	40E, 500E		870
1977	700, 800, 900	+	+
1975	1150, 1400, 1500		
1968	1750, 2000		
1979	402E, 500E, 650, 650XS	▪980	▪980
1977	700, 850, 850XS	or	or
	1150 above Serial #439661	■■981	■■981
	1500, 1500 SX above Serial #4351590		
	1750		
1979	**MARINER OUTBOARDS**	2024	
1976	8, 9.9, 15, 25, 30, 40, 60 (2 cyl.)	2034	
	With 80 watt lighting coil	1024	
		1034	
THRU		1024	
		1029	870
		1034	+
	50-200	1039	▪980
	(except 2 cyl. 60)	+	or
		▪980 or	■■981
		■■981	
	CHRYSLER OUTBOARDS		
1979	350, 1, 2, 3, 4, 5, 6, 7, 360, 1		
1976	450, 1, 2, 3, 4, 5, 6, 7, 8, 9, 464, 8		
1969	507, 554, 5, 6, 7, 8, 9		
	608, 609, 659		
THRU	706, 707, 709, 756, 757, 758	1024	
	850, 856, 857, 858, 859, 906, 907, 908	2024	
	1006, 1007, 1008	1034	
	1056, 1057, 1058, 1059	2034	
	1156, 1157, 1158, 1159		
	1206, 1207, 1208, 1209, 1258		
	1356, 1357, 1358, 1359		
	1406, 1407, 1408, 1409		

MODEL 2030—FOR 5 AMP. JOHNSON AND EVINRUDE ALTERNATOR

1977-1982 10, 15, 25, 35 ELECTRIC START	1981-1983 50 ELECTRIC START
1978-1979 55 ELECTRIC START	1980-1983 60 ELECTRIC START

YEAR	Model Number	TACHOMETER Series 10 & 20	TACHOMETER Sea Speed 2
	JOHNSON OUTBOARDS		
1979	70 ELCR, TLCR	1029	
1978	75 ECR, TLCR	2029	
1974	90 MLCR	1039	870
	115 MLCR	2039	+
		+	■■■962
		■■■982	
	EVINRUDE OUTBOARDS		
1979	70 ELCR, TLCR	1029	
1978	75 ECR, TLCR	2029	
1974	90 MLCR	1039	870
	115 MLCR	2039	+
		+	■■■982
		■■■982	
1979	**SUZUKI OUTBOARDS**	2024	1024
1978	8, 9.9, 16, 25, 40, 50, 65	2034	1034
1970	With 80 watt lighting coil		
THRU		2024	1024
		2029	1029
	85 115 140	2034	1034
		2039	1039

ANY SPECIAL APPLICATION NOT ON CHART CALL FACTORY—800-621-3058

▪No. 980 Three wire Harness connects indicator to throttle control box.

■■No. 981 Four wire Harness as above for power Trim models.

■■■No. 982 Wiring Harness
For use with Johnson and Evinrude Outboards using Command and Center II or Power Pilot System.

▪Five wire Harness is used on Mercury and Mariner V-6 engines. Mercury number 84-86396A4.